

RONSON®


TECH TORCH® Auto Start

Disassembly Instructions

See Video at www.RonsonRecall.com/disassembly .


STEP 1:

Manually twist the nozzle (Metal Burner Shield) counter clockwise until the narrow metal tube beneath it separates from the nozzle.




STEP 2:

Pull the metal tube down and away from the unit.
Remove the tube to expose wire.



STEP 3:

Using a pair of scissors, cut the wire as close as possible to the trigger unit to disable the lighting function of the Tech Torch.



STEP 4:

Return the metal tube and wire to Zippo in the envelope provided with your Return Kit.



ALTERNATIVE METHODS TO SEPARATE TUBE:

